

USB Flash Drive Part Number System

1 ~ 2	3	4	5 ~ 7	8 ~ 10
Case Design	Speed	Brand	Capacity	Attribute/Color
AC	■ = Value	B = Blank	128 = 128MB	B or BL = Blue
AD	A = 120X	F = "SuperUSB"	256 = 256MB	BK = Black
AE	B = 200X	S = "SuperTalent"	512 = 512MB	BS = Blue Haze
AH	R = ReadyBoost		1GB = 1GB	CB = Clear Blue
AN			2GB = 2GB	CBK = Clear Lid on Black
AR			4GB = 4GB	CC = Clear Clear
BC			8GB = 8GB	CO = Clear Orange
BP			16GB = 16GB	CR = Clear Red
DC				CSB = Clear Lid on Sky Blue
DE				FG = Fortune God
DG = DGN				G = Green
DH				GD = Gold
DL				GY = Grey
FB				H2 = Panda w/ Scarf
GP				H3 = Panda w/ Broom
LS				RT = Rubber Tiger
PF				LN = Lion
RC				MX = Military Fatigue
RF				P = Purple
SA				PB = Pearl Blue
SB				PBK = Pearl Black
SW				PG = Pearl Green
SE = SWAE				PW = Pearl White
SM = SWM				R = Red
				RB = Rubber Blue
				RBK = Rubber Black
				RF = Rubber Frog
				RO = Rubber Orange
				RR = Rubber Red
				RS = Rubber Silver
				RV = Rubber Violet
				RW = Rubber White
				S = Silver
				S6 = Silver 6 Holes
				SB = Sky Blue
				T = Tan
				TBK = Transparent Black
				W = White
				WB = White w/ Blue
				WBK = White w/ Black
				WW = White w/ White
				XMS = XMAS