


SUPER★TALENT™

Digital music player

Quick Guide

I. Key definition



- ① Power Switch (ON/OFF/HOLD)
- ② Earphone Jack
- ③ Play/Pause
- ④ LED
- ⑤ Next Track
- ⑥ Previous Track
- ⑦ Volume up
- ⑧ Volume down
- ⑨ USB Jack

SUPER★TALENT™

II. Operation

- 1、Power on: Slide the Power Switch from Off to ON, then press Play button.

- 2、 Power off: Slide the Power Switch from ON or Hold to Off.
- 3、 Play/Pause: Press Play button to play music or to pause, the LED will flicker when music starts to play.
- 4、 Next/Previous : When music is playing, Pressing (▶▶) key for next song, Press (◀◀) key for previous song.
- 5、 Volume up/down: When music is playing, Pressing (+) key for Volume up Press (-) key for volume down.

III. Download Music

- 1、 Connect the player to the computer via USB cable.
- 2、 Transfer your music from the PC to the player.

IV、 Charging the Battery

- 1、 If the battery level is low, please charge it immediately. You may charge the player via USB cable connection with the computer.
- 2、 When the battery is recharging, the LED will blink. When it is fully charged the LED will be off.

VI、 Specification

Built-in Memory: 1GB

Battery: Rechargeable lithium battery

USB Interface: Hi-Speed USB2.0

Operating system: Windows 2000/XP/Vista

Note: Specifications subject to change without prior notice.